



# Slipper - Free-standing Bath

## PRODUCT CODES

WHITE BATH:	FC458-01	SLIPPER-1680-CAST-WEISS
BLACK BATH:	FC458-23	SLIPPER-1680-CAST-BLK
	FC458-01-M	MODERN SLIPPER-1680-CAST-WEISS

## FREE-STANDING BATH

BATH WIDTH:	700 mm
BATH HEIGHT:	555 mm
BATH LENGTH:	1680 mm
BATH VOLUME:	170 lt
WASTE SIZE:	52 mm
OVERFLOW SIZE:	40 mm

The Slipper Bath is a Free-standing bath.

## SLIPPER FREE-STANDING BATH INSTALLATION GUIDE:

1. Before assembly of the feet, place a soft piece of material on the floor. This will protect the bath when you place the bath top down on a flat surface.
2. Remove the protective rubber pad from the four threaded inserts and blow out any dust. These pads help protect the bath prior to installation, but the bath should still not be transported or dragged on these pads.
3. Please insure that the threaded inserts have been inspected for cracks. If there is any damage, please report this to the retailer immediately.
4. The Slipper baths use different feet on the front and back. It is important to use the correct feet at each end to ensure a close fit to the bath and prevent damage to the bath. The single ended feet (with one big crown on the top) is marked SB on the back and must be fitted on the front of the Slipper (low end of the bath).

The double ended feet (with three part crown on the top) is marked FS on the back and must be fitted on the back of the Slipper (high end of the bath). All other cast baths use the same feet on all four corners.

5. By hand, screw the bolt with two washers (smaller one nearest the bath) part way into an insert.
6. Slide the plate off the foot between the two washers and make sure the foot fits flush with the bath. Screw the bolt in as far as possible by hand. Using a torque wrench, tighten the bolt using not more than 15mm of force. Using too much force will break the insert out of the casting.

7. Turn over the bath and place in position. The feet are designed to hold the weight of the bath, complete with water and user. It is not suitable to transport the bath mounted on the feet or drag the bath with the feet mounted.

Should the bath need to be moved during the installation process, the bath must be picked up and carried with the feet clear of the ground at all times. Care should be taken when putting the bath down to prevent sudden impacts which could break a foot off.

8. Connect the tap-ware to the service outlet and the waste to the trap outlet.



## AVAILABLE COLOURS:

