



Valencia Suite - Top Flush

PRODUCT CODES

WHITE:	XTVAT08A	SUITE-VALENCIA TF-WHI
CISTERN:	CU0708A CU03**A TC06**A	CISTERN-BIBO TF-WHI CISTERN-BIBO TF-** PANS-ASTINA-**
PAN:	STBE1P08	SEAT-BEMIS-WHITE
SEAT:	FMDFBW01	MECH-UNIVERSAL DUAL FLUSH (WIRQ)
MECH:	XTAST08A	FIX-PAN FIXATIONS (BOLTS&PLUGS)
FIXATION:		

| CLOSE COUPLE, OPEN RIM, TOP FLUSH |

WEIGHT OF PAN:	17kg
WEIGHT OF CISTERN:	11.7kg
CISTERN WATER CAPACITY:	9l
PAN FLUSH VOLUME:	4/7l
PAN WIDTH:	360mm
PAN HEIGHT:	415mm
CISTERN WIDTH:	340mm
CISTERN HEIGHT:	415mm
COMBINED HEIGHT:	805mm
INSTALLED MAX LENGTH:	670mm



AVAILABLE COLOURS:



Valencia Top Flush is a close-couple, open rim suite.

VALENCIA SUITE INSTALLATION GUIDE:

- Step 1 - Fit inlet valve and flushing mechanism, as per manufacturer's instructions.
- Step 2 - Attach cistern to pan using fixation bolts.
- Step 3 - Fit seat, use the manufacturer's instructions.
- Step 4 - Place the pan with cistern on flat (even) surface for best results.
- Step 5 - Make markings on floor surface, for drilling of fixation holes (pan).
- Step 6 - Remove Pan and cistern, drill holes into concrete floor.
- Step 7 - Slide outlet of pan onto bung of outlet pipe-fitted by a qualified plumber.
- Step 8 - Attach pan to floor using screw fixations.
- Step 9 - Connect to the water supply.

